




# Sequence of Operation – Utility Failure

## for Series 165 Automatic Transfer Switch

Read and understand the **Owner's Manual** before installing, servicing, or operating. Failure to do so could result in serious personal injuries or property damage.

- light is on
- light is off



4016 Quartz Drive  
 Santa Rosa, CA 95405  
 Phone: 707 539-9003  
 Fax: 707 539-5212  
 Email: sales@generatorjoe.NET  
 Web www.generatorjoe.NET



# GeneratorJoe

381339-222 A